PALLET RACKING

IMPORTANT - ASSEMBLY INSTRUCTIONS

Tools required: Rubber mallet, electric drill, metric spanners and spirit level


IMPORTANT

1. Pallet Racking must only be erected on flat and level concrete capable of withstanding the applied load.
2. Racking must be floor fixed with the anchors provided.
3. Follow safe working procedures - check your health and safety policy.
4. When installing the system, we recommend that no person should be higher than 2m from the ground without the use of safety harnesses.
5. High bay pallet racking must be installed by experienced installers using suitable handling equipment - forklifts and scissor lifts.


If in doubt, ask for our installation service.

A

Fit beams at bottom to stabilise first bay, insert safety pins




B



We advise the use of protective gloves and goggles, or eyeglasses when assembling this product.

Fit upper beams at desired level and remove bottom beams

C



Add extension bays

Fit safety pin through beam connector and post

Check levels with a spirit level. Shims may be inserted below the footplate to level the rack, fit floor anchor through footplate and shims


If you have any problems whatsoever please call **01452 223098** where a team of experts will be pleased to help.

AIR002

PALLET RACKING

IMPORTANT - ASSEMBLY INSTRUCTIONS


SAFETY



Allow sufficient clearance for pallet overhang.

Note the orientation of frames and positions of row spacers

For back to back systems, fix row spacers with 4 No M8 x 25



Ensure all loads are uniformly distributed and adequate clearances are maintained.

If in doubt ask for advice



Fix load charts to each run of racking

If you have any problems whatsoever please call **01452 223098** where a team of experts will be pleased to help.

AIR002