
# **MEDIUM DUTY SHELVING**




### **ASSEMBLY** - 6 shelf bay 1980mm high

- 1 Fit plastic feet **E** to uprights **A**.
- 2 Assemble both ends first A and B starting from the bottom. For optimum clear entry allow 8 clear holes between each shelf support B.
- 3 Tap together using rubber mallet.
- **4** Join both ends using front and rear beams **C**.
- **5** Add shelves **D**.

# **MEDIUM DUTY SHELVING**

#### **COMPONENTS**



#### **SAFETY**

